

# **BIG BIKE PARTS®** **INSTALLATION INSTRUCTIONS** **BRAKE AND CLUTCH** **LEVER INSTRUCTIONS**

Copyright© 2000 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc™

Revised 06/05/07

WHEN INSTALLING BRAKE & CLUTCH LEVERS THERE ARE IMPORTANT FEATURES TO BE CHECKED BEFORE USE.

1. LEVERS SHOULD BE ABLE TO BE ENGAGED AND DIS-ENGAGED FREELY.
2. MOST LEVERS WHEN ENGAGED & DIS-ENGAGED ACTIVATE SWITCHES, VERIFY THIS BY LISTENING FOR THE SWITCH “CLICK” NOISE WHEN ENGAGING & DIS-ENGAGED. MAKE SURE THE SWITCHES ARE WORKING BEFORE USE.

**NOTE: FOR ADJUSTABLE LEVERS, PUSH THE LEVER FORWARD AND THEN TURN THE DIAL TO ADJUST THE DISTANCE FROM THE GRIP TO THE LEVER.**