

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

LED Volt Meter

Fits Most Vehicles

Part No. 13-303

Copyright© 2006 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

NOTE: DEALER INSTALLATION RECOMMENDED

1. LOCATE AN AREA IN WHICH YOU WISH THE VOLTMETER TO BE INSTALLED AND CLEAN WITH A RUBBING ALCOHOL OR CLEANING SOLVENT.
2. ADHERE THE VOLTMETER TO THE DESIRED LOCATION.
3. ROUTE THE WIRES FOR THE VOLTMETER UNDERNEATH ANY AND ALL PANELS, SEATS, FRAMES AND TANKS TO HIDE THE WIRE FROM VIEW MAKING SURE YOU CAN REACH THE ACCESSORY TERMINAL FOR THE BIKE. THIS IS USUALLY LOCATED NEAR THE BATTERY.

NOTE: IF YOUR BIKE DOES NOT HAVE AN ACCESSORY TERMINAL ANY SWITCHED POSITIVE POWER LINE CAN BE USED.

4. INSTALL THE WIRES FOR THE VOLTMETER TO THE ACCESSORY TERMINAL OR SWITCHED POWER SOURCE. RED FOR POSITIVE, BLACK FOR NEGATIVE.
5. TURN KEY ON AND CHECK FOR CORRECT OPERATION.
6. REPLACE ANY PANELS OR COVERS THAT WERE REMOVED.

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

LED Volt Meter

Fits Most Vehicles

Part No. 13-303

Copyright© 2006 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

NOTE: DEALER INSTALLATION RECOMMENDED

1. LOCATE AN AREA IN WHICH YOU WISH THE VOLTMETER TO BE INSTALLED AND CLEAN WITH A RUBBING ALCOHOL OR CLEANING SOLVENT.
2. ADHERE THE VOLTMETER TO THE DESIRED LOCATION.
3. ROUTE THE WIRES FOR THE VOLTMETER UNDERNEATH ANY AND ALL PANELS, SEATS, FRAMES AND TANKS TO HIDE THE WIRE FROM VIEW MAKING SURE YOU CAN REACH THE ACCESSORY TERMINAL FOR THE BIKE. THIS IS USUALLY LOCATED NEAR THE BATTERY.

NOTE: IF YOUR BIKE DOES NOT HAVE AN ACCESSORY TERMINAL ANY SWITCHED POSITIVE POWER LINE CAN BE USED.

4. INSTALL THE WIRES FOR THE VOLTMETER TO THE ACCESSORY TERMINAL OR SWITCHED POWER SOURCE. RED FOR POSITIVE, BLACK FOR NEGATIVE.
5. TURN KEY ON AND CHECK FOR CORRECT OPERATION.
6. REPLACE ANY PANELS OR COVERS THAT WERE REMOVED.

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

LED Volt Meter

Fits Most Vehicles

Part No. 13-303

Copyright© 2006 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

NOTE: DEALER INSTALLATION RECOMMENDED

1. LOCATE AN AREA IN WHICH YOU WISH THE VOLTMETER TO BE INSTALLED AND CLEAN WITH A RUBBING ALCOHOL OR CLEANING SOLVENT.
2. ADHERE THE VOLTMETER TO THE DESIRED LOCATION.
3. ROUTE THE WIRES FOR THE VOLTMETER UNDERNEATH ANY AND ALL PANELS, SEATS, FRAMES AND TANKS TO HIDE THE WIRE FROM VIEW MAKING SURE YOU CAN REACH THE ACCESSORY TERMINAL FOR THE BIKE. THIS IS USUALLY LOCATED NEAR THE BATTERY.

NOTE: IF YOUR BIKE DOES NOT HAVE AN ACCESSORY TERMINAL ANY SWITCHED POSITIVE POWER LINE CAN BE USED.

4. INSTALL THE WIRES FOR THE VOLTMETER TO THE ACCESSORY TERMINAL OR SWITCHED POWER SOURCE. RED FOR POSITIVE, BLACK FOR NEGATIVE.
5. TURN KEY ON AND CHECK FOR CORRECT OPERATION.
6. REPLACE ANY PANELS OR COVERS THAT WERE REMOVED.