

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 20-115
20-118

15" E-Z SHIELD 1" BARS
18" E-Z SHIELD 1" BARS

TOOLS NEEDED:

3/16" ALLEN WRENCH

5/32" ALLEN WRENCH

TAPE MEASURE

1. ATTACH THE WINDSHIELD MOUNTS (A) TO THE MOUNT FRAME (B) USING 5/32" ALLEN WRENCH AND 1/4" - 20 X 3/4" BUTTON SOCKET HEAD CAP SCREWS (C). DO NOT FULLY TIGHTEN AT THIS TIME.
2. MEASURE THE DISTANCE TO THE OUTSIDE OF THE HANDLEBAR RISERS. THEN CENTER THE BOTTOM HALF OF THE CLAMPS (D) ON TO THE MOUNT FRAME (B) WITH 1/4" - 20 X 1 1/2" SOCKET HEAD SCREWS (E) INTO THE FLAT NUT (F) AND SLIDE INTO T-SLOT IN MOUNT FRAME (B). ONCE IN POSITION, TIGHTEN DOWN COMPLETELY USING THE 3/16" ALLEN WRENCH. MAKE SURE EACH CLAMP IS THE SAME DISTANCE FROM THE OUTSIDE OF THE MOUNT FRAME (B) AND ARE ORIENTED CORRECTLY.
3. USING THE 5/32" ALLEN WRENCH, ATTACH THE UPPER CLAMPS TO THE HANDLEBAR LOOSELY WITH 10 - 32 X 1" SOCKET HEAD SCREWS (H) SO THAT THE POSITION AND ANGLE OF THE MOUNT FRAME (B) CAN STILL BE ADJUSTED.
4. USING THE 5/32" ALLEN WRENCH AND 1/4" - 20 X 5/8" BUTTON SOCKET HEAD SCREWS (J), FASTEN THE WINDSHIELD TO THE WINDSHIELD MOUNTS (A).
5. CENTER THE CLAMP ON THE HANDLEBAR, ADJUST THE ANGLE AND HEIGHT OF THE WINDSHIELD, AND TIGHTEN ALL SCREWS.

NOTE: WHEN CLEANING THE WINDSHIELD, NEVER USE ABRASIVE CLEANERS, HOUSEHOLD CLEANERS, WINDOW CLEANING FLUIDS, SCOURING COMPOUND, GRITTY CLOTHS, OR STRONG SOLVENTS SUCH AS ALCOHOL, ACETONE, CARBON TETRACHLORIDE, ETC.

NOTE: TO MAINTAIN THE BRILLIANT LUSTER OF LUCITE, WAX OCCASIONALLY WITH A PREMIUM GRADE AUTOMOTIVE WAX. (NOT A CLEANER/WAX COMBINATION.) APPLY A THIN COAT WITH A CLEAN COTTON CLOTH. THEN WIPE WITH A CLEAN DAMP CLOTH. NEVER USE HOUSEHOLD SPRAY WAXES.

NOTE: WE RECOMMEND USING THREAD LOCKER ON ALL HARDWARE.

